

ATX Extended Adapter Kit (300-80049-00)

European (Black)

L 000-80023-00		L1 000-80024-00
M 000-80025-00		M1 000-80026-00
N 000-80027-00		N1 000-80028-00
AV 000-80029-00		AV1 000-80030-00
99 000-80047-00		
33 000-80057-00		34 000-80058-00
VO 000-80049-00		
35 000-80051-00		
31 000-80050-00		
37 000-80056-00		
40 000-80068-00		41 000-80069-00
38 000-80066-00		39 000-80067-00

BMW & Mercedes	1985 & newer	M & M1 or Ford (Gold): G & G1
BMW Flare Adapter	up to 1985	N & N1
BMW O-Ring Adapter	1987 & newer	L & L1
BMW w/ Quick Connect Adapter		37 & 3/8 in. Female Hose
Saab 14 mm Fittings		33 & 34
Volvo, Jaguar, Mercedes	1985 to 1992	Ford (Gold): C & C1
Volvo	1992 to 1998	AV & AV1 & 99
Volvo	1996 & newer	31 & 1/2 in. Female Hose
Volkswagen	All Models	VO & 35 (2 of each req'd)
Land Rover & Range Rover	1996	40 & 41
Range Rover	1997	38 & 39

(Adapters shown in BLUE are included in Standard Adapter Set)