

Generation One and Two RRC750 Compressor Replacement

1. Remove bottom (black) perforated panel and middle (red) panel from the RRC750.
2. Locate the compressor in the bottom (left side) of the RRC750. Follow the lower of the two 3/8" copper lines on the front of the compressor up into the middle section of the RRC750. Disconnect the plastic tubing attached to the end of this copper line.

Note: A minimal discharge of refrigerant will result. Emptying of the RRC750's Charging Cylinder is unnecessary as valves inside the RRC750 prevent this from occurring.
3. Follow the upper 3/8" copper line on the front of the compressor to the Suction Pressure Regulator (SPR) valve. Disconnect the line on the **top** of the SPR valve and remove it with the compressor so it can be attached to the new compressor prior to installation.
4. Remove the plastic cover from the wiring compartment of the compressor. Discharge the start capacitor (start capacitor is the tall black cylinder attached to the right of the compressor wiring compartment) by shorting a screwdriver across the two leads of the capacitor before removing them.
5. Remove the four mounting nuts/screws holding the compressor down, and the two wire ties holding the Oil Level Sight Tube in place.
6. Remove the compressor from the RRC750.
7. Leaving the covers on the ports until compressor is installed (this prevents oil spillage); remove the SPR valve and install it on the new compressor.
8. Install the new compressor using the provided mounting hardware.
9. Reconnect the SPR valve, and the plastic line removed earlier.

Note: See the instructions included in the Nylon Tube Kit provided if the plastic tube fitting on the new compressor is of a different style than that used in your RRC750.
10. Assemble electrical box and attach wire harness. Refer to the Electrolux Compressor Wiring document (560-80242-00).
11. **Do not add any oil to the compressor**, it left the factory pre-charged and there is no maintenance required on this compressor.



RTI Technologies, Inc.
4075 East Market Street
York, Pennsylvania 17402 USA
Phone: 717-840-0678
Fax: 717-755-8304
Web-site: www.rtitech.com
E-mail: tech@rtitech.com